

Vinyl Signs Application

TOOLS REQUIRED

- Masking tape
- Smoothing tool - squeegee or ruler
- Measuring tape or ruler
- Spray bottle - with warm water and a few drops of dishwashing liquid

VINYL SHEET CONSISTS OF THREE LAYERS:

- Top Layer - see-through transfer paper
- Middle Layer - vinyl lettering
- Bottom Layer - backing paper

APPLICATION STEPS:

1. Place the slimline divider onto the back edge so the front is facing the ceiling. Make sure the rounded back corners are on the top of the divider.
2. Clean surface and ensure it is dry before commencing application.
3. Place your vinyl sign sheet on the front of the slimline divider.
4. Use one piece of masking tape across the top of the sign to adhere the sign sheet to the slimline divider to create a hinge.
5. Ensure that the sign is straight by measuring to either edge of the slimline divider, top and bottom.
6. Flip up the sign sheet and spray the surface of the slimline divider with your spray bottle.
7. Peel off the backing paper. Be careful that all the lettering remains attached to the transfer paper. The masking paper is now working as a hinge.
8. Slowly lower the vinyl sign sheet and working from top to bottom firmly press down on the transfer paper (with your smoothing tool) to smooth out any bubbles as you lower the sheet. Leave for an hour to adhere to the surface.
9. Use your smoothing tool to ensure there are no bubbles under the vinyl. Lightly spray the transfer paper with water then carefully peel off the transfer paper from the top to reveal your letters. If you notice any letters are pulling up with the transfer paper, re-rub onto the surface and work any bubbles to the nearest edge.
10. Gently dry with cloth