










## HOW TO PAIR 156X / 166X BLUETOOTH SCANNERS TO IPODS / IPHONES AND IPADS

Please follow below instructions to establish a connection with your Apple device.

**Step 1:** Scan below barcodes in number order. Please insure you hear the scanner beep each time you scan. When scanning keep at least 3 inches of gap between the scanner and the barcodes.

1.	 Enter Setup
2.	 109993 Restore System Defaults
3.	 100065 Transmit By: Character
4.	 100006 Activate BT HID & Select Keyboard Type
5.	 109906 6
6.	 109904 4
7.	 109994 Validate
8.	 101023 Use POWER Key to Show or Hide Keypad




**Step 2:** On your Apple device go to *Settings / General / Bluetooth*.

- a) Switch the Bluetooth ON by sliding the Bluetooth button to the right (see image below).
- b) Your Apple device will start searching for the scanner; at this point insure the scanner is awake by pressing its trigger and noticing the red light appear.
- c) Scanner's serial number will appear in the Bluetooth Devices list on your Apple device.

**Step 3:** Pairing the scanner.

- a) Continued from point C above, tap the scanner's serial number from the Devices list.
- b) The Apple device will prompt you with a PIN code and the prompt will last approximately 30 seconds, enough time for you to scan the PIN code, see sample image below...



- c) For this example you must scan barcodes below, **Enter PIN Code In Decimal, 0950 (4 Barcodes)** then **validate**.
- d) If you make a mistake tap the serial number under Bluetooth devices to start over.
- e) When pairing is successful; open **Notes** on your Apple device and test by scanning a random barcode such as a tissue box, a Coke can etc...



100151

Enter PIN Code In Decimal



109900

**( 0 )**



109901

**( 1 )**



109902

**( 2 )**



109903

**( 3 )**



109904

**( 4 )**



109905

**( 5 )**



109906

**( 6 )**



109907

**( 7 )**



109908

**( 8 )**



109909

**( 9 )**



109994

Validate

For support or any questions please contact:

**Marwan**

**Technical Support and Sales**  
**JRC International Pty Ltd**  
**Ph. 02 9621 3377 Fax: 02 9831 4878**

Email: [marwan@jrc.com.au](mailto:marwan@jrc.com.au)  
WEB: [www.jrc.com.au](http://www.jrc.com.au)