

MINI GLUE GUN & STICKS

HOT MELT GLUE GUN & STICKS

26 August 2020

YOUR SMART ADVANTAGES

- Fast, clean and versatile adhesive
- Designed to fit neatly in the hand
- Easy to load and use trigger action
- High bond strength

DESCRIPTION

Bostik Mini Glue Gun, using Bostik Mini Glue Sticks provides an instant, clean and versatile adhesion to a myriad of household and craft materials.

USES

Bostik Mini Glue Gun is designed for DIY tasks and household repairs, hobby, craftwork, and home décor projects.

Instantly bonds most craft and household materials including, fabric, wood, leather, most plastics, ceramics and metal.

PRODUCT CHARACTERISTICS	
Туре	Trigger action glue gun
Product codes Glue Gun, 4 per carton Glue Sticks, 10 per carton	30803736 30803735
TYPICAL PERFORMANCE DATA (approx.)	
Rated voltage	100-240 volts
Rated input power	8-20W
Rated frequency	50/60Hz
Heating Element	Posistor temperature co-efficient (PTC thermistor)
Protection against electric shock	Class II
Equipment mobility	Portable
Type of power connection	Permanently attached flexible cable with plug
Recommended hot melt	Bostik Mini Craft Glue Sticks - translucent Diameter: 7.2mm Length: 100mm

Application	Glue is released from
	gun by trigger action

PREPARATION

- Locate a pair of pin holes on each side next to the gun nozzle.
- Attach the metal stand into the pin holes. After attaching the stand, the gun can sit in an upright position when the stand is pulled down or extended. Always use the stand.
 - Never lie the gun down on its side when in use or whilst cooling down as this will cause gun failure.
- Ensure parts to be glued are dry, clean and free from grease and dust.

APPLICATION

- 4. Insert Bostik Mini Glue Stick gently through tunnel at back of gun. Never use excessive force as the glue stick will clog the channel.
- 5. Plug cord into an electrical outlet and wait 5 minutes to heat up the glue. Ensure glue is hot or glue will not extrude through the gun. Using the glue gun before the glue is fully heated may cause the glue to be forced into the inner chamber of the gun and cause electrical shorting.
- 6. Apply adhesive by gentle continuous pressure, to the more difficult surface to bond (usually smooth surfaces are more difficult to adhere than rough, porous surfaces). Release trigger to stop flow of glue. Glue does not need to be spread. <u>Do</u> <u>not touch molten adhesive</u>, as temperatures around 200°C will cause serious burns.
- Join surfaces as quickly as possible for optimum bond strength.
- 8. To bond *foam products* (polystyrene foam etc.) to another surface, apply adhesive in an "S" pattern to the surface to which the foam will be bonded, rather than directly to the foam.
- 9. To bond *fabrics*, use a smaller "S" pattern for additional strength.
- When you have finished using the gun, switch off and unplug it and allow to cool completely before storing.
- 11. Allow the glue stick to remain in the gun do not remove stick from rear of gun at any time.

Bostik Australia Pty Ltd, Level 1, 6 English Street, Essendon Fields, Victoria, 3041, Australia. Tel: +61 3 9279 9333 www.bostik.com/au

Version 1 Page 1 of 2

BOSTIK Mini Glue Gun & Sticks

REMOVAL

- Small drops of glue can be easily removed by scraping when cold.
- 13. Residual glue can be remelted and removed from most bonded surfaces with a warm knife.

STORAGE AND SHELF LIFE

Store in a cool dry area, below 30 °C and out of direct sunlight. Shelf life for the Bostik Mini Craft Glue Sticks is 24 months when stored under recommended conditions.

HEALTH & SAFETY

Always read the Technical Data Sheet and Safety Data Sheet (SDS) before handling or use. Full product safety information required for safe use is not included in this data sheet. SDS available by request or at www.bostik.com.au

PRECAUTIONS IN USE

Recommendations and suggestions are for guidance only, since conditions of use are completely out of our control.

For domestic use only

- 1. Recommended for light assembly jobs.
- Do not allow the nozzle of the heated gun to make contact with any surface as it may cause damage. Hot molten glue may damage some surfaces.
- 3. Do not leave gun unattended and unplug cord when not in use.
- 4. Children should only use the gun under adult supervision.
- 5. Do not use the gun in damp or wet conditions or expose it to rain.
- Never put any object in the gun other than the glue sticks recommended.
- 7. The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- 8. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

For emergency information contact the Poisons Information Centre, phone 131 126 or the Emergency Response Service, phone 1800 033 111.



This datasheet is for the general help of users. It is provided in good faith. The data is current and accurate to the best of our knowledge. Differing materials, substrates, environments, site conditions, and product storage, handling and application may affect results. Users should carry out tests to decide the product's suitability for purpose. This data sheet and the properties of the product may change without notice. Users, suppliers and retailers should check that the data sheets they have are the latest. To the maximum extent permitted by law, Bostik disclaims all warranties in relation to manufacture and use of the product. Bostik is not liable for representations made by users, suppliers or retailers about the product. Bostik is not liable for any loss or damage resulting from incorrect, careless, or negligent use or storage of the product, including use of out of date product. Any liability arising from use of the product is limited to the replacement or purchase price of the product. Bostik does not exclude rights and remedies that cannot be excluded by legislation, for example under the Australian Consumer Law (ACL). Sale of the product by Bostik is subject to the Bostik Australia Proprietary Limited Conditions and Terms of Sale. For more information on Bostik, products, and conditions of use and sale visit www.bostik.com/au